








Not suitable for children under 36 months due to small parts, choking hazard.

©Disney

®\* and/or ™\* & © 2002 Hasbro. All Rights Reserved.
® denotes Reg. U.S. Pat. & TM Office.
3860 PN 6164600000










## Step

Slide main deck and top deck together as shown. Snap in place securely.











## Step

Attach front rails (2) and rear rails (2) onto bridge as shown.

Press-fit projectile launchers into battle bridge stations.



**S**tep



Step Cannon Sub-Assembly

Press and turn muzzle to attach. Fit "control arm" onto footplate. Slide foot plate onto cannon base.



Step Bow Sprit Sub-Assembly

Fit bow sprit base onto ship's bow.
Press-fit long piece into base.

Slide "radar sensor" onto assembled unit.

Step Step

